User Manual

RG200mwRed and green stars



Thank you very much for buying double hole -RG200MW red green 24 pattern effect full sky star. For your personal safety and better use of the product, please read this manual carefully before use, and operate according to the regulations, so as not to misuse the personal safety and light damage.

Products and functions:

The design and production of our products are all evaluated and controlled in a comprehensive way. It is strictly required to meet the quality standards and ensure the superior performance of the products, and to meet the expectations and requirements of the customers to the maximum extent. The product light source adopts the agreement with the international laser generator standard. It can be used on a single station, or online combined with a wide range of applications. It can be used widely and widely. This manual should be kept with the luminaire for emergency needs. Semiconductor laser generator, laser light source long life, high stability, very simple operation, humanized design, dimming without flickering, jitter phenomenon. It can be adapted to photography, photography, TV stations and other occasions that require strict lighting.

• Packing list:

When you turn on the laser light box, please check the following items:

•••-RG200MW: double hole -RG200MW red green 24 pattern effect

••• - - RG200MW double red hole green red 24 pattern

effect star sky power line

•••• - - RG200MW double red hole 24 red and green design effect

• security Directive:



Prevent electric shock, eye damage, environmental protection packaging

! Before installing and repairing the lamps, please confirm that the power supply of the lamp body is disconnected. Please ensure that the blower fan outlet is well ventilated and the surrounding environment is well ventilated. Do not use this product in a wet environment for a long time.

! Please prevent lamps from touching water droplets during indoor use or maintenance. If used for

outdoor use, please do adequate waterproof measures.

Installation note:

1, installation position: before the positioning and installation of the lamps and lanterns, to ensure the stability of the installation point, to consider the long vibration and time of the wear and tear, bearing at least ten more bearing structure of the large product.

2, the installation process: first check the lamps and lanterns hook and screws are complete or normal. A professional lamp is usually used to hook M8-12 bolts and fix the installation through a nut equipped with a fixture: the safety rope is sent through the installation of the handle or the other safety hanger of the lamps and lanterns, and then the required angle and position are adjusted. When installing lamps and lanterns, it must ensure that its position is stable, and pedestrians are not allowed to walk under the lamps. Valuables or fragile items should not be placed below as far as possible, so as not to damage them. After installation of lamps and lanterns, check the safety rope regularly for a few days to see if there is any loosening and wear. In the removal of lamps and lanterns to turn off the power supply to ensure its safety, first untie the safety rope, and then remove the hook or hanging lamp, but also to ensure the safety of pedestrians below.

3. After the lamp is installed, the laser lamp should be energized to avoid direct or indirect shooting into people's eyes, and keep the distance between the lamp and combustibles above 0.8 meters. Try to ensure that lamps do not turn on frequently, or strong vibration / impact, do not jitter use.

Product technical parameters:

Rated voltage: AC110V /230V + 10%

Rated frequency: 50Hz ~ 60Hz

Rated power: 20W

Laser power: G:30mw/532nm R:100mW/650nm Laser color: emerald green; red

Mode setting: serial number mode switch position

Single computer sound control mode: SOUND

Self walking mode of single machine: AUTO

Cooling system: forced cooling system of fan

Working environment: Indoor

Lamp size: 20*14*12/ CM Carton: one loading one: 23X19X15CM

Net weight: 1.5KG gross weight: 2KG

One load of 8:47X39X33CM

gross weight: 15KG

Pattern setting

| Serial number | Pattern | Switch position |
|------------------|-------------------------------------|-----------------|
| 1 | Single computer sound control mode | SOUND |
| 2 | Single machine self walking mode | Αυτο |

Maintenance:

1. Try to prevent dust, dirt and smoke from artificial laying or even flowing into the lamp body, the use of the environment as far as possible to keep the laser performer clean;

2. Please use professional glass cleaning agent regularly every month and clean the mirror with flannelette so as to ensure the maximum laser output and prolong the service life of the light source.

Notice of warranty

Warranty period: This product is guaranteed for one year from the date of purchase.

Warranty clause:

1. The failure to use this product within the normal state of the warranty may, according to the warranty clause, produce this warranty card and purchase instrument (copy), and enjoy the free maintenance service at the seller's or the production plant.

2. During the warranty period, paid maintenance service will be implemented in the following situations.

(1) no effective warranty card can be produced.

(2) the warranty card is marked by omission and no sales name.

(3) failures and injuries caused by force resistance.

(4) failure and damage caused by transportation and unloading.

(5) failure or damage caused by failure to use instructions.

(6) failure or damage caused by dismantling, repair or modification of the product without authorization from the manufacturer or by a non professional person. Failure caused by non factory approval or non factory control series.

(7) consumables - our factory's final interpretation of this warranty clause.